

Kettle Handle Instructions

Cam and Set Screw Style

1. Unplug the popcorn machine from the AC outlet.
2. Remove the kettle from the machine.
 - a. Unplug the kettle plug from the chassis (ceiling.)
 - b. Put the kettle in the open position. (hanging)
 - c. Pull the clip from the hinge pin.
 - d. While holding the kettle, slide the hinge pin out of the hinge bracket.
3. Put the kettle upside down on a flat surface.
4. Slide the handle rod through the front bracket hole ONLY on the kettle.
5. Slide the cam onto the handle rod (see photo.)
6. Slide the spring over the handle rod (see photo) and then push the handle rod through the back bracket hole.
7. Align the set screw in bottom of cam with the flat surface on the kettle handle rod and tighten the set screw using a 2mm Allen Wrench.
8. Attach the spring to the cam as shown in photo.

